


8018 CE Quick Start Guide



Change Language: English by default. Pressing the navigation key to the Setting contents, then choose Phone --> Language.

1. Configuring network

Dynamic mode by default. Phone UI change path: Pressing the navigation key to the Setting contents, then choose Admin (Default password: 123456) --> IP param --> IP Config --> Ipv4 Settings --> Ipv4 Mode.

2. Configuring account

Users can configure account via phone UI or WEB UI. WEB UI example.

Step 1: Pressing navigation key to the Settings --> Network interface to view the IP address

Step 2: Entering https://IP address on the browser. Login with "admin" and password "123456"

Step 3: Configuring account as below

Status	Account	General	Basic	Codec	Advanced	Network
Account:	Account1	SIP Label Name:		Register Name:	52009	
Display Name:		Password:	*****	User Name:	52009	
SIP Server:	192.168.1.100	SIP Server Port:	5060			

Note: Marked items are mandatory. Please contact service provider for detail.

Step 4: Account status shows "Registered" when the SIP account is registered successfully.