



AH80 Bluetooth Headset

User Manual

Version 1.1 | February 2023

Alcatel·Lucent 
Enterprise

Legal Notice

This document is created by ALE China Co. Ltd. (hereinafter referred to as "ALE China"). Anyone who accesses and uses this document shall agree to comply with the following clauses. If you do not agree to comply with these clauses, please do not use this document. ALE China reserves the right to update, correct and modify the following clauses at any time without notice, and these updates will also be binding on you.

Trademark Notice

The Alcatel-Lucent name and logo are trademarks of Nokia used under license by ALE China.

Copyright Notice

The copyright of any content (including but not limited to data, text, graphics, images, sound or video, etc.) provided in this document belongs to ALE China. You may not copy, reproduce, transmit, publish, repost, adapt or display the content of this document in any way without the prior written permission of ALE China. Any unauthorized use of this document will violate the Copyright Law of the People's Republic of China and other laws and regulations as well as the provisions of relevant international conventions.

Disclaimer

While efforts were made to verify the completeness and accuracy of the information contained in this documentation, this document is provided "as is". To get more accurate content concerning Cross Compatibilities, Product Limits, Software Policy and Feature Lists, please refer to the accurate documents published on the Business Partner Web Site.

In the interest of continued product development, ALE China reserves the right to make improvements to this documentation and the products it describes at any time, without notice or obligation.

The user shall be solely liable for any loss or damage (including direct, indirect, special or consequential loss or damage) arising from the use of the information contained herein for any reason whatsoever.

To the extent permitted by law, ALE China reserves the right of final interpretation.

This document is only authorized to be used under the purpose of performing the contract obligations under the relevant contract signed with ALE China and shall not be used for other purposes.

Content

1. Introduction	4
2. Headset overview	5
3. Accessories	6
4. Connection	7
5. Wearing the headset	8
6. Charging	9
7. Using the headset	10
7.1 Call handling	10
7.1.1 Answering/Rejecting a call	10
7.1.2 Ending/Holding a call	10
7.1.3 Mute on/off	11
7.1.4 Status light change/off	11
7.1.5 Handling multiple calls	12
7.2 Activating voice assistant	12
7.3 Music mode	13
7.4 Settings	13
7.4.1 ANC/Transparency mode	13
7.4.2 Customizing prompt languages	14
7.4.3 Restoring factory settings	14
7.5 Checking the battery level	15
8. Indicator lights	16
9. Support	18
10. Maintenance	19
11. Warning	20

1. Introduction



Thank you for purchasing the Alcatel-Lucent Enterprise AH80 Bluetooth Headset. We hope you enjoy it.

This User Manual will get you started and help you make the most of your headset.

Features

- HD audio technology & cVc noise cancellation
- Retractable microphone boom
- Up to 45 hours battery life & wireless charging capability
- Advanced Active Noise Cancellation (ANC) and transparency mode for you to hear your surroundings better
- Bluetooth connection range of up to 75 meters (laboratory data)
- Compatibility with mainstream Unified Communications (UC) platforms and deskphones
- Multi-language voice prompts supported: Chinese, English, French, German, Spanish, Portuguese and Italian

2. Headset overview



3. Accessories


Make sure you have the following items in the package with your headset:



Carry case



USB-A to USB-C charge cable



3.5mm aux cable



USB dongle

Note: The actual product may differ in appearance from the images shown.

4. Connection


Connecting AH80 to your PC, deskphone or smartphone/tablet

- USB Dongle



Plug the USB dongle into your PC or deskphone and slide the switch to the middle position to power on AH80. AH80 will connect with the dongle automatically.

- Bluetooth



Slide the switch to the end position and hold for 2~3s to power on AH80 and enter pairing mode. Then, power on Bluetooth on your Bluetooth device and select AH80 for pairing.

- 3.5mm Aux Cable




When AH80 runs out of power, you can also connect via a 3.5mm aux cable to listen to music or for communication.


Note: If you connect a 3.5mm aux cable into AH80 in powered-on state, AH80 will enter into powered-off state when you can use it as a wired headset. To use Bluetooth, you will need to unplug the 3.5mm cable, slide the switch to the OFF position and then turn it back on.



5. Wearing the headset




Adjust the headband to make a comfortable fit for your head.



The microphone boom is retractable. You can pull it out closer to your mouth to achieve optimal sound and hide it when listening to music or watching movies.


6. Charging

- USB cable



Plug the Type-C connector at one end of the USB cable into AH80 and the Type-A connector into the charger or PC. It takes approximately 2 hours to fully charge the headset. It is recommended to use a DC 5V 1A charger.

- Wireless charging



Put the left earphone onto the wireless charging base. It takes approximately 2.5 hours to fully charge the headset. It is recommended to use a Qi-certified wireless charger.

Note: When fully charged, the headset provides around 35 hours of talk time and up to 45 hours of playback time.




7. Using the headset

7.1 Call handling

7.1.1 Answering/Rejecting a call


When there is an incoming call, you can control it via the multi-function button (MFB) on the right earphone.



Multi-function button

- **Answer a call:** Press the MFB
- **Reject a call:** Press twice the MFB

7.1.2 Ending/Holding a call



Multi-function button


While on a call, you can

- **end a call:** Press the MFB
- **hold/Resume a call:** Hold the MFB for 1 second

7.1.3 Mute on/off

During a call, you can


- **mute/unmute your microphone:**
Press the Mute button



7.1.4 Status light change/off


While on a call, you can switch the status light between red, blue and off. When needed, you can use red light to indicate busy state and blue light to indicate available state. The headset saves and remembers last output state of the status light after power off.

- Change/Turn off the status light:**
Hold the Mute button for 2 seconds
(Red/Blue/Off)





7.1.5 Handling multiple calls




Multi-function button

While there are multiple incoming calls, you can

- **end the current call to accept the incoming one/end the incoming call and resume the call on hold:** Press the MFB
- **reject the incoming call:** Press twice the MFB
- **put the current call on hold and answer the incoming one/put the incoming one on hold and resume the original call:** Hold the MFB for 1 second

7.2 Activating voice assistant




Multi-function button

In idle state, you can

- **activate your voice assistant** (e.g. Siri, Google Assistant or Alexa): Hold the MFB for 1 second

7.3 Music mode



Play/Pause music: Press the MFB

Volume up: Tap the Volume + area

Volume down: Tap the Volume - area

Previous track: Press and hold the Volume - area for 1 second


Next track: Press and hold the Volume + area for 1 second

7.4 Settings

7.4.1 ANC/Transparency mode


You can control the ANC mode and switch to transparency mode via the ANC button. In transparency mode, you can hear the world around you without taking off your headset.

ANC mode on/transparency mode on/ANC mode off: Press the ANC button




7.4.2 Customizing prompt languages

The headset supports multiple voice prompt languages, including Chinese, English, French, German, Spanish, Portuguese and Italian. To switch between languages, press the MFB and ANC button simultaneously for over 2 seconds.




Multi-function button



7.4.3 Restoring factory settings


Factory reset the headset:

Press both the Mute button and the ANC button simultaneously for more than 6 seconds



7.5 Checking the battery level


When the headset is powered on and no Bluetooth device is connected, you can check the battery level by listening to the voice prompt.



Multi-function button

Listen to remaining battery percentage voice prompt: Press the MFB

8. Indicator lights



Powered off/standby mode



Pairing



Bluetooth connected



On for 10s | More than 70% power remaining



On for 10s | 30%~70% power remaining



On for 10s | 10%~30% power remaining



On for 10s | Less than 10% power remaining



Charging above 70%




Charging 30%~70%



Charging 10%~30%



Charging less than 10%




- Powered off | Standby/Music mode
- Powered on | On for 10s
- ☀ Charging
- Fully charged | On for 10s
- ☀ Incoming call alert
- Busy (on a call or meeting)
- Rebooting/Updating firmware
- Upgrade completed



9. Support

The ALE Go app helps you boost your headset performance through regular firmware updates.



Download ALE Go to stay tuned for the latest firmware updates available.

- Select an EQ mode
- Customize the prompt language
- View the User Manual
- Perform firmware upgrades



10. Maintenance

- Please store your headset in the carry case that it came in when not in use.
- To prevent battery depletion, please avoid storing your headset in a too hot or too cold environment (e.g. in the car in summer or winter).
- Keep the headset from getting wet. If the headset gets wet, leave it long enough to dry fully before powering it on.
- It is recommended to keep the headset at a temperature between -10°C and 45°C (23°F and 113°F).
- Do not store the headset for long periods of time without charging. It is advisable to charge the battery at least once every six months to maintain its performance.



11. Warning



Do not listen at high volume levels for long periods.

AH80 Bluetooth Headset User Manual

www.aldevice.com

